

B1/B1N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if a standard wood crossarm is used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- Tie in conductors

Removal

- Untying conductors
- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Untying and Retying of conductors
- Removal and/or Installation of Specified Units in accordance to Construction Specification Drawing - Note: if a standard wood crossarm is used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located

B1-1/B1-1N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- Tie in conductors

Removal

- Untying conductors
- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Untying and Retying of conductors
- Removal and/or Installation of Specified Units in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located

B1-2/B1-2N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if a standard wood crossarm is used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- Tie in conductors

Removal

- Untying conductors
- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Untying and Retying of conductors
- Removal and/or Installation of Specified Units in accordance to Construction Specification Drawing - Note: if a standard wood crossarm is used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located

B1-3/B1-3N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- Tie in conductors

Removal

- Untying conductors
- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Untying and Retying of conductors
- Removal and/or Installation of Specified Units in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located

B2/B2N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- Tie in conductors

Removal

- Untying conductors
- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Untying and Retying of conductors
- Removal and/or Installation of Specified Units in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located

B7/B7N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- See appropriate M42 specification for deadend shoe requirements

Removal

- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Remove conductors from shoes and secure conductors back into new shoes
- Removal and/or Installation of Specified Units in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located

B8/B8N

Labor shall be based on the following:

Construction

- Assemble in accordance to Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- When required, install jumpers in accordance to the Construction Specification Drawing – Note the phase conductors' route over the top of the crossarm and tied to one (1) crossarm pin insulator each.
- See appropriate M42 specification for deadend shoe requirements

Removal

- Disassemble framing
- All Removed Material shall be returned to the District Storeroom in which the project is located

Replacement

- Remove and Install jumpers as required - install jumpers in accordance to the Construction Specification Drawing – Note the phase conductors' route over the top of the crossarm and tied to one (1) crossarm pin insulator each.
- Remove shoes and secure shoes to new attachment point
- Removal of existing framing and Installation of Specified Unit in accordance to the Construction Specification Drawing - Note: if standard wood crossarms are used a crossarm protector is required. Alternative would be a specially treated wood crossarm or a fiberglass crossarm. Verify type of crossarm specified for the project.
- When required, install jumpers in accordance to the Construction Specification Drawing – Note the phase conductors' route over the top of the crossarm and tied to one (1) crossarm pin insulator each.
- If armor rod is existing, verify removal before installation of new unit
- Labor and Temporary Material needed to support conductors during framing and/or a re-conductor project to keep the existing line energized. (i.e. "buddy arms")
- All Removed Material shall be returned to the District Storeroom in which the project is located